

### STEP 1:

准备好开盖器底座  
Prepare the Delid Partner



### STEP 2:

将CPU放进底座内部的凹槽  
Put the CPU into the Delid Partner



### STEP 3:

将上盖A盖在CPU上  
Cover the top cover A on the CPU



### STEP 4:

拧紧二颗螺丝  
Tighten the two screws



### STEP 5:

用扳手拧紧上部的螺丝，使上盖A移动，  
打开CPU上盖  
Use a wrench to tighten the upper screw, moves cover A, open the CPU cover



### 恢复CPU顶盖(Restore the CPU cover)

将CPU放进底座内部的凹槽；将CPU顶盖装入上盖B里面，在顶盖涂上适量704硅胶，压在CPU上，  
拧紧二颗螺丝，静置24小时，待胶水固化后拆开螺丝，取出CPU。

Put the CPU into the base of the groove; Put the CPU cover into the cover B, apply a suitable amount of 704 silica gel on the top cover, pressed on the CPU, Tighten the two screws, place 24 hours until the glue is cured, open the screw, take out the CPU.

